

1. FILTRATION SETTINGS

Clear Comfort should be **ON** during filtration cycle (the Clear Comfort system's green light should be **ON**).

- Preferred filtration time for circulation pumps: 24 hours/day (standard for most newer models)
- Minimum filtration time for all other programmable 2 speed pumps: 12+ hours/day

***Note:** Most factory preset times are to less than 12 hours/day.




Takes **5 min.**
Perform **once**

2. MEASURE AIR FLOW

A steady stream of bubbles should be entering the spa.

- Set flow rate to 3-5 LPM using dial on Flow Meter


***Note:** Please keep the flow meter with the Clear Comfort system for future use



Takes **5 min.**
Perform **monthly**

3. WATER CARE

- **Important!** Start with clean, fresh spa water. Spa purge products are recommended for older spas. Upon filling with new water, shock using a non-chlorine shock (MPS).
- Clear Comfort's powerful oxidation process can reduce the required residual level & the need for shock treatments.
- Regularly balance water levels 2X per week:
 - pH: 7.2 - 7.4
 - Alkalinity: 80 - 120 ppm
 - Calcium Hardness: 50 - 250 ppm
- Brush & wipe down spa surfaces as needed.
- Shock your spa as needed, especially after high-use periods.



Takes **10 min.**
Perform **bi-weekly**

4. FILTRATION MAINTENANCE

- Maintain and clean filters 1X - 2X every two weeks
- For high use spas: Cleaning should occur 1X per week

***Note:** A dirty filter can have a negative effect on water quality & reduce air flow through the Clear Comfort system




Takes **10 min.**
Perform **weekly**

5. REPLACE CARTRIDGE

If the yellow light on the Clear Comfort system is ON, your Cartridge needs to be exchanged & returned to Clear Comfort for proper recycling.

1. Turn off Clear Comfort system using front switch.
2. Rotate the cable base on top of the Cartridge Unit a quarter turn & gently pull up.
3. Remove Air Tubing from the Cartridge Unit.
4. Remove old Check Valve from Air Tubing & replace with new Check Valve.
5. Remove the Cartridge Unit from Control Unit.
6. To attach Cartridge Unit, repeat steps in reverse.

▶ For video instructions, please visit: clearcomfort.com/video-cartridge



Takes **5 min.**
Perform **annually**